

Vážený zákazníku, děkujeme Vám za důvěru, kterou jste nám projevil nákupem tohoto výrobku.

Čtěte pozorně tento návod a uschovejte ho pro další použití.

OBSAH BALENÍ

Obsah balení předního světla, zadní blikačky, nebo sady osvětlení. Dle typu světlo, držák a baterie.

Příslušné baterie typu AA, AAA, CR2032 apod.

POUŽITÍ

Vždy používejte stejný typ baterie, který byl dodán v originálním balení. Dle typu světla otevřete kryt odšroubováním, vysunutím, nebo rozevřením v místě drážky mincí. Dle typu vyjměte pásku vloženou pod baterii proti vybíjení.

Při vkládání baterií dbejte na jejich správnou polaritu! Pokud osvětlení delší dobu nepoužíváte, vyjměte baterie - zamezíte jejich vytečení a následné oxidaci kontaktů. Nepoužívejte staré baterie s novými.

Světlo upevněte dle typu do objímek, držáků, případně gumovým úchytem na řídítka (přední světlo) a na sedlovku (zadní světlo). Celé zasunutí světla do držáku je většinou provázáno cvaknutím.

Dle typu u držáků stlačte pojistku-páčku pro uvolnění světla. Světla se zapínají, vypínají a jejich režimy přepínají stiskem, případně opakovaným, nebo dlouhým stiskem tlačítka umístěným na těle světla.

UPOZORNĚNÍ

Vyvarujte se přímého pohledu do zapnutého světla. Abyste zabránili nežádoucímu osvětlení ostatních chodců a cyklistů vždy směřujte úhel světla směrem dolů. Vždy sejměte světlo při čištění a skladování kola ve venkovních prostorách (chraňte před deštěm a sněhem). Světlo vždy vypněte, pokud ho nepoužíváte. Světlo používejte na dobře větraném místě v exteriéru, hrozí riziko přehřátí. Světlo může rušit funkci ostatních elektronických přístrojů (např. cyklistické tachometry).

Kapacita baterie se snižuje při nižší okolní teplotě. Nevystavujte světlo ani baterii vysoké teplotě +40°C (např. na horkém místě v autě), dlouhodobě nízkým teplotám pod 0°C, vysoké vlhkosti a přímému slunečnímu záření. Skladujte na chladném, suchém místě mimo dosah dětí, zdrojů tepla a hořlavých materiálů. Chraňte před ohněm a vznětlivými látkami.

Neponořujte světlo pod vodu. Světlo je voděodolné, lze ho tedy používat za mírného deště.

Při silném dešti doporučujeme světlo uschovat na suchém místě. Neomývejte vodou a nepoužívejte agresivní čističe.

Nerozebírejte ani jinak neupravujte světlo, baterii a příslušenství. Po uplynutí životnosti zlikvidujte baterii ekologicky dle platné vyhlášky. Vždy se řiďte platnými dopravními zákony o osvětlení v zemi, kde produkt používáte.

ZÁRUKA

Záruka nemůže být uplatněna na poškození způsobené vystavením nadměrným teplotám, mechanickým poškozením, neodborným servisním zásahem, úpravami, neodbornou montáží nebo nesprávným použitím. Dodavatel nepřijímá žádnou odpovědnost za zranění nebo jiné škody způsobené nesprávným použitím tohoto výrobku za jakýchkoli okolností.



Dear Customer, thank you for your confidence in purchasing this product.

Read this manual carefully and keep it for future reference.

PACKAGE CONTENTS

Headlight, rear flash light or light set. By light type: light, holder and appropriate battery AA, AAA, CR2032 etc.

USE

Always use the same type of battery which was included in the original packaging. Depending on the type of light, open the cover by unscrewing, ejecting, or opening by the groove with coin. Depending on the type, remove the foil inserted under the battery against discharge. Pay attention to the correct polarity when inserting batteries! If you don't use the light for an extended period of time, remove the batteries to avoid leakage and oxidation of the contacts. Do not use old batteries with new ones.

Fasten the light to the clamps, brackets on the handlebar (headlight) and the seatpost (rear light). With most of the lights, full insert into the bracket will be accompanied by a click sound. Depending on the type, press the light release lever to release the light. The lights are turned on, off, and their modes are switched by press/ double press or long press of the button on the light body.

NOTICE

Do not look directly into the light. To prevent from blinding oncoming riders and walkers always adjust the light angle downwards. Always dismount the light while cleaning the bicycle and storage outside (protect from rain and snow).

Switch the light off if not used. Use the light in well ventilated place outdoors – risk of overheating. Light and battery can cause interference of other electrical devices (computers). Battery capacity decreases at lower temperature.

Do not expose the light or the battery to a high temperature of + 40 ° C (hot place in the car), low temperatures under 0 ° C, high humidity and direct sunlight. Store in a cool, dry place, keep away from children, fire, heat source and inflammable material. Do not submerge in water. Light is water-resistant, it can be used in light rain.

During heavy rain, it's recommended to store on a dry place. Do not clean with water or aggressive cleaners.

Do not disassemble or otherwise modify the light, battery and accessories. Dispose the battery ecologically according to valid regulations. Always follow applicable traffic laws on lighting in the country where you use the product.

WARRANTY

Warranty does not apply to damage due to high and low temperatures, physical damage resulting from abuse, improper repair, improper fit, alternations of the fixture or improper use. Importer does not accept any liability for injuries or other damage resulting from improper use of this product under any circumstances.

